GAMIAC

One more game

TKL69G

Mechanical Gaming Keyboard

Kailh hot swappable switch supports 50M strokes
Durable PBT keycaps with excellent typing feel

a.   Quick Start Guide
b.   USB cable
c.   Kailh hot swappable switch x2
d.   Keycap and switch puller

|		
FN +	(3S)	Long press to default setting
	1	F1
	2	F2
	3	F3
	4	F4
	5	F5
	6	F6
	7	F7
	8	F8
	9	F9
	0	F10
	-	F11
	=	F12
	A	Mac OS
	S	Win OS
	WIN	WIN key lock
	☀	RGB backlight brightness ↑ (5 levels)
	☀	RGB backlight brightness ↓ (5 levels)
	☼	RGB backlight direction adjustment
	⬤⬤	RGB backlight color change
	DIY	Backlight customization **(*1)**
	⊕	RGB backlight speed ↑
	⊖	RGB backlight speed ↓
	☀	Change RGB light effects (18 total)
	☒	RGB backlight off

(*1) **RGB DIY:**
1. Press FN + ~ (DIY) to activate RGB customization.
2. Press FN + ~ (DIY) again, and the LED indication (A) & (1) will flash at the same time.
3. There are 9 backlight color modes (including backlight off) to select. Keep pressing the key you would like to customize the RGB backlight color.
4. Press FN + ~ (DIY) again to complete the customization setting.

■ **Connecting to your PC**

a. Connect the keyboard to the PC using the USB C to USB A cable.
b. The keyboard will be detected by Windows within 5-30 seconds.
c. The keyboard is now ready for use.

■ **LED indication**

A	1	M	⚡

A: CAPS LOCK   (blue LED)
M: Mac OS layout   (blue LED)
⚡: USB connection   (blue LED)
1 : no specific function

Unable to detect keyboard on PC
• Make sure the computer meets the minimum system requirements.
• Try connecting the keyboard to a different USB port on the computer to ensure that the USB cable isn't damaged and is correctly plugged in.
• If the issue persists, enter your computer's settings and make sure the keyboard language is set to match the product's configuration.

Hot swappable keyboard switches

a. Take off key caps with a keycap puller.
b. Pull out the switch with a switch puller.
c. Ensure the shaft of the switch is correctly aligned with the socket.
d. Accurately place the new switch on the socket.
e. Gently press the switch into the socket.
f. Install the key cap back onto the switch.

www.gamiac.com

CE FC UK CA

CB 20 PAP RoHS Compliant

紙

FR Cet appareil se recycle

REPRISE À LA LIVRAISON À DÉPOSER EN MAGASIN OU À DÉPOSER EN DÉCHÈTERIE OU

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !